

**WINDOW FILM
ASSEMBLY SEQUENCE**
(starting with completed wood frame)

- 1. Label frame (on top outside edge)**
- 2. Apply double stick tape (1st layer)**
- 3. Stretch on the film**
- 4. Trim off excess film**
- 5. Apply double stick tape (2nd layer)**
- 6. Stretch on the film**
- 7. Trim off excess film**
- 8. Apply 2” packing tape**
- 9. use hair dryer to shrink the film**
- 10. apply pull tabs**
- 11. Apply foam weather strip**

Tools:

**Scissors, utility knife, cordless drill,
hair dryer, tape measure, packing tape gun.**